



NATIONAL OPTICAL ASTRONOMY OBSERVATORY

950 N. Cherry Ave.
P. O. Box 26732
Tucson, Arizona 85726-6732
(520) 318-8000
FAX: (520) 318-8303

**TORRENT
KIT PARTS LIST
TSM Covers Kit**

**Dwg No.: TRNT-EL-02-0021 Rev: OD
NEXT ASSEMBLY: TRNT-EL-02-0003**

LTR	DESCRIPTION	ECR	DATE	BY	APPRVD
OD	INITIAL RELEASE		7-Jul-11	DMS	

ITEM	QTY	BINLOC	SEE NOTE	Part Number	MFR	Description
1	REF			TRNT-EL-02-1029	NOAO/CNTRCT	Base Front Cover
2	REF			TRNT-EL-02-1030	NOAO/CNTRCT	Base Top Cover
3	1					Plastic bag 10" x 10" size
4	1					Plastic bag 8" x 8" size
5	2					Plastic bag 3" x 4" size (small)
6						

NOTES:

1. Reference: TRNT-EL-02-0003 Transition Module Assembly, photos on page 3.
All items shown on assembly may not be part of this kit.
2. Bag sized are specified as minimum size necessary.
3. Place fastener hardware for Base Top cover in one of the small bags, label with "Top Cover Hardware" if not already labeled, place top cover and bagged hardware in the 8x8 bag.
4. Place fastener hardware for Base Front Cover in a small bag, label with "Front Cover Hardware" if not already labeled, place front cover and bagged hardware in the 10 x 10 bag.
5. Put the bagged items from step 3 into the larger bag containing items from step 4, make sure hardware is not between covers.
6. Seal large bag and fold over excess, put in proper inventory location.



Image shown is 2 kits, to get a view of both sides